

INTERMEDIATE TRAINING OBJECTIVE 2B

PERFORMANCE TEST

TRANSFERRING FLATRACK (FR) ONTO PLS TRAILER FROM TRUCK

NAME_____ RANK_____ UNIT_____

EVALUATOR_____ DATE_____

<u>STEPS</u>	GO	NO-GO
1. CHECKS FOR OVERHEAD OBSTRUCTIONS.		
2. IF FR IS LOADED WITH CARGO, CHECKS ISO LOCKS OR CARGO TIE-DOWNS FOR SECURITY.		
3. CHOCKS TRAILER WHEELS. CHECKS CONTROL KNOB POSITION (TRAILER BRAKES SHOULD ALREADY BE SET).		
4. ENSURES BOTH TRAILER FLATRACK LOCKS ARE RELEASED.		
5. LOWERS TRAILER DRAWBAR FULLY.		
6. BACKS TRUCK IN LINE WITH THE TRAILER. TRAILER BUMPER SHOULD BE SQUARE WITH TRUCK BUMPER AND IN FULL CONTACT.		
7. SETS PARKING BRAKE ON TRUCK.		
8. SETS HYDRAULIC SELECTOR LEVER TO AUTOMATIC (AUTO) POSITION. MOVES JOYSTICK TO "UNLOAD" UNTIL FR IS DOWN ONTO TRAILER. (IF DONE BY ONE PERSON, GETS OUT OF THE TRUCK AND CHECKS FR ROLLERS AT FIRST CONTACT TO ENSURE THEY ARE RUNNING PROPERLY ON THE TRAILER TRACK).		
9. SETS HYDRAULIC SELECTOR TO MANUAL HOOK ARM (MAN HA) POSITION AND MOVES JOYSTICK TO "LOAD" UNTIL THE FRONT OF FR IS RAISED ABOUT 12 TO 18 INCHES ABOVE TRAILER DECK HEIGHT.		
10. SETS HYDRAULIC SELECTOR TO MANUAL MAIN FRAME (MAN MF) AND MOVES JOYSTICK TO "UNLOAD" UNTIL FR ROLLERS CONTACT STOPS AT BACK OF TRAILER OR UNTIL TRUCK SUSPENSION IS FULLY UNLOADED. (THE CONTACT WITH THE STOP CAN BE SENSED IN THE TRUCK, BUT VISUAL INSPECTION IS REQUIRED.) DOES NOT CONTINUE UNLOADING AFTER FR CONTACTS THE STOPS. IF FR IS NOT AT THE STOPS, REPEATS STEPS 9 AND 10.		

STEPS

GO NO-GO

11. RELEASES TRUCK PARKING BRAKES AND MOVES JOYSTICK TO "UNLOAD" MOMENTARILY (TO MOVE TRUCK AHEAD SO FR RESTS FULLY ON TRAILER).
12. TO RELEASE LHS HOOK, PUTS TRUCK IN DRIVE, MOVES JOYSTICK TO LOAD MOMENTARILY, THEN TO UNLOAD AS TRUCK IS INCHED FORWARD (NO MORE THAN 2 TO 3 INCHES).
13. SETS PARKING BRAKES ON TRUCK.
14. SECURES FR LOCKS ON TRAILER BY PULLING LOAD LOCK CONTROL KNOB.
15. MOVES THE TRUCK FORWARD ABOUT 5 FEET.
16. SETS SELECTOR LEVER TO AUTOMATIC (AUTO) POSITION AND MOVES JOYSTICK TO "LOAD" UNTIL LHS IS FULLY BACK ON TRUCK (LHS NO TRANSIT LIGHT IS EXTINGUISHED).
17. SETS SELECTOR LEVER TO "OFF" POSITION FOR DRIVING VEHICLE. (IT IS IMPORTANT TO SET LEVER TO OFF TO AVOID OVERHEATING OF HYDRAULIC SYSTEM.)

[illegible]